## **PROGRAMMING INSTRUCTIONS FOR**

## **Dial Combination Lock**

## Installation Instructions:

- · Fits standard 3/4" cam hole
- Short cam can be placed in increments of 90 degree positions
- Long cam can be positioned in increments of 45 degrees
- 1. Insert lock body through front of 3/4" drilled hole.
- 2. <u>Wood Only</u>- place prong washer over lock body, prongs facing wood.
- 3. Thread cylinder nut & tighten.


4. Attached stop cam and straight cam and secure with screw and lock washer. **Note:** Stop cam placement





will rotate left

Cam



Instructions for setting your personal combination:

- The combination is factory set at >>0-0-0<<
- · Combination must be on opening number prior to resetting
- On the underside outer edge of the lock there is hole for the code reset button. Rotate the face of cam until the code reset button comes into view.
- Push this pin in with a paper clip and keep it pushed in.
- Set your personal combination by turning the dials to the desired combination.
- · Release the reset button and your combination is set.
- To lock, rotate lock to "locked" position. Rotate one or more dials after lock is closed. To open the lock, turn dials to your personal combination.