

INSTRUCTIONS FOR

Stack & Connect Label Dispenser (#12721)



Step 1. The 10 roll dispenser includes 9 removable dividers and the 20 roll does not include dividers. Both dispensers include 4 adhesive protective feet that attach to the bottom.



Step 2. Attach the 4 protective feet to the bottom corners.



Step 3. Insert clear plastic dividers into each grooved slot.



Step 4. Your dispenser will look like this with all dividers in place.

Call Free: 1.800.848.1633 • Fax Free: 1.800.447.2923
Web: GoHCL.com • Email: hcl@GoHCL.com

INSTRUCTIONS FOR

Stack & Connect Label Dispenser (#12721)



Step 5. Insert blister packed labels into each compartment formed by the dividers.



Step 6. Pull out the first few labels on the roll and slide them down into the label guide on the front of the dispenser. (The first couple of labels will need peeled by hand).



Step 7. Pull the label liner.



Step 8. Shut the lid and pull the label liner until a label is automatically peeled and dispensed below the top lid.

Call Free: 1.800.848.1633 • Fax Free: 1.800.447.2923

Web: GoHCL.com • Email: hcl@GoHCL.com