

ASSEMBLY INSTRUCTIONS FOR

Temperature Recorder Kit (#8251, 8252, 8248, 8249, 8263)

Quick Start

1. This recorder comes with 1 AA battery installed.
2. Remove battery door
3. Set switch on back of unit to the appropriate motor speed: 7 day or 24 hour.
4. Remove battery and reinsert carefully. Avoid bending the battery terminal.
5. Replace chart paper, with a new chart.
6. Set the time by inserting a coin into the chart hub and turning clockwise until the correct hour is referenced by the time indicator. (Time indicator is directly to the right and below the pen tip.)
7. Remove protective pen cap.
8. The chart movement is self-starting and runs continuously. Allow unit to stabilize in environment for 15 minutes.
9. SL4 Only: To switch the display between F & C, use the back of a pencil to press the F/C button located on the back of the unit.