

# INSTRUCTIONS FOR HCL® Packout System, 7-Quart (#20364)



## Contents Included:

- Transport Cooler, 7-quart
- Two Cold Packs
- Two Small Corrugated Plastic Dividers
- Packout Instructions

## Not Included:

- USB Probe Data Logger with Glycol Bottle Probe
- Cellophane Packing Bags
- Cardboard Box



### Step 1.

Place one frozen cold pack in the bottom of the cooler.



### Step 2.

Place one corrugated plastic divider over the cold pack.



### Step 3.

Place one USB Probe Data Logger that has been chilled to approximately 40°F inside of a cardboard box.



### Step 4.

Fill dead space with cellophane packing bags.



### Step 5.

Place second corrugated plastic divider over box.



### Step 6.

Place second frozen cold pack on top as the last item and close the lid.

Call Free 1.800.848.1633 • Fax Free 1.800.447.2923

Web: GoHCL.com • Email: hcl@GoHCL.com