

# INSTRUCTIONS FOR (#8222) Stainless Steel Narcotic Cabinets Shelf Clip Instructions



**Step 1.** The shelf clips for mounting the shelves should be positioned with the curved tab on top and the L-shaped tab on the bottom.



**Step 2.** Select your proper shelf height and insert the top tab of the shelf clip into one of the rectangular holes inside the cabinet.



**Step 3.** When the top tab is snapped in, squeeze the bottom tab to the next lower hole, snapping it in place. Place shelf on clips.

**Note:** For tilted shelves, place the front clips three positions lower than the rear clips. It is easiest to put all the shelves in the cabinet first and then hold the shelf and position the clips to the proper height. If clips are in place or some of the shelves are in place, it is very difficult to fit the remaining shelves into the cabinet.